

CONTENTS

1	Door Gasket
1	Instructions

NOTES:

- The door gaskets are made of a vinyl and may become temporarily distorted from shipping. Read Gasket Preparation Procedure below to remedy this.
- Always carry gaskets by corners, this will help prevent further distortions and possible damage to magnets.

INSTALLATION (GASKET PREPARATION)

- 1 Allow gasket to reach room temperature before removing from the shipping carton.

⚠ CAUTION

Hair dryers get extremely hot and can melt door gaskets! Use extreme caution to avoid over-heating!

- 2 Gaskets do have a "memory" to their original shape, so distortions are temporary. To aid in returning gasket to original form, immerse gasket in WARM water, or lay gasket on flat surface, then use a hair dryer and CAREFULLY pass heat over distorted area(s), keeping hair dryer 8" to 10" away from gasket.

200, 300, 500, 600, 600-2 Series (except model 245)

- 1 To remove existing gasket from door, "loosen" all gasket retainer screws with a 1/4 nut driver and pull gasket's back flange from under ridge of gasket retainers.
NOTE: On 500, 600 and 600-2 Series doors, the gasket is installed prior to foaming the door. This may allow foam to leak through some screw holes. Before attempting to install new gasket, all residual foam must be scraped from door edge with a straight blade screwdriver or putty knife.
- 2 Apply "thin" bead of general purpose, white, adhesive silicone to door where gasket will be seated.
- 3 Install new gasket over gasket retainers, tucking gasket's back flange under ridge of the retainers.

⚠ CAUTION

Do not over-tighten screws! Doing so may strip screw holes. If this should occur, use an alternate #10 screw (part # 6200150).

- 4 Tighten gasket retainer screws, starting along bottom of door, then work each side, then along top of door.
NOTE: Door gaskets are no longer demagnetized on handle side of 500, 600 or 600-2 Series gaskets. The new gasket may make the door much harder to open. If so, see Gasket Demagnetizing Instructions (not provided).
- 5 Check for proper door sealing and adjust door if needed.

700, 700-2, 700-3 Series (including model 245)

⚠ CAUTION

Top drawer assemblies in 700, 700-2 and 700-3 Series Base units have a control cable that must be disconnected at interior back left corner of upper drawer compartment before removing drawer fully. Failure to disconnect cable could damage cable or connectors. See NOTES below before proceeding.

NOTES: For top drawer of 700, 700-2 and 700-3 Base units:

- Open top drawer 6" to 10", lift up off of pins at front, push drawer slides in and carefully lay drawer face down directly in front of unit.
 - Disconnect cable at interior back left corner by turning collar counter-clockwise and pulling.
- 1 To remove existing gasket from door or drawer, pull gasket's back dart from the gasket retainer channel.
 - 2 Install new gasket by inserting gasket's back dart firmly into gasket retainer channel.

